

# FC-088 F-16 Fighter Plane



# **Specification**

Dimension L195 x W130 x H130 cm


Weight 130 kgs

Voltage 110V AC, 60Hz, 3A, Max 6A

220V AC, 50Hz, 3A, Max 6A

#### F-16 FIGHTER PLANE FRP Model Assembly

#### F-16 FIGHTER PLANE Detail Manual



#### **SIDE VIEW**

- 1. Acrilan cover#1
- 2. Light#1
- 3. Steering wheel#2
- 4. Electronic coin machine(key#1)
- 5. Coin box(key#2)
- 6. Maintenance door-medium(key#1)
- 7. Light#2
- 8. Light#3
- 9. Power-plug locates at rear of base


- 10. Fixer
- 11. Wheel
- 12.Control door(key#1)
- 13.Double frame
- 14.Music box
- 15.Controller
- 16.Base of cloud shape
- 17.Ladder
- 18.Handlebar#1
- 19.FRP model of F-16 Fighter Plane


s1~s5. Sticker

s6. Warning sign sticker

FC-P0001 Double Frame

### **Double Frame Wire Manual**






size: W188mm x L78mm x H113mm

FC-P0003 Controller

# **Controller Operating Manual**



Count: Adjust the coin from 1 coin to 5 coins

**Stop Button:** For Checking machine without insert coin to "STOP" the machine **Start Button:** For Checking machine without insert coin to "START" the machine

Reset: Red lighting when power connect

Start: Green lighting when machine start to working

#### 1~12 play Time adjust:

1. 1 Minute and 30 Seconds 7. 3 Minutes and 30 Seconds

2. 1 Minute and 40 Seconds 8. 4 Minutes

3. 1 Minute and 50 Seconds 9. 4 Minutes and 30 Seconds

4. 2 Minutes 10. 5 Minutes

5. 2 Minutes and 30 Seconds 11. 10 Seconds for testing


6. 3 Minutes 12. 0



Page 3
Contents

### FC-M0003 Music Box

## Music Box Operating Manual




- 1. 1-12: Sound volumes adjust
- 2. Sound buttom connection
- 3. Power light: When power connect
- 4. Counter: Coin Counter
- 5. Music: 12 English kiddy songs to repeat




Page 4
Contents

FC-P0026 Electronic Coin Machine

# **Electronic Coin Machine Operating Manual**





size:mm

Page 5 Contents

#### FC-P0026 Electronic Coin Machine

### **Electronic Coin Machine Operating Manual**

# DIDGITAL COMPARABLE ELECTRONIC

INSTALLATION HI-07CS+LED

STEP1

Cheng the right coin for use from the clamp.

STEP2

Adjust the right insert size for use from the front panel back side.

STEP3

Select the right mode: Normal Open/ Normal Close" TIMER SWITCH" for synchronizing your system.

100ms (Slow Speed/Long Pulse)

50ms (Medium Speed/ Medium Pulse)

30ms (Fast Speed/ Short Pulse)

STEP4

Adjust VR sensitivity tunning

Clockwise: slack selection (LED dark->light)
Anti-clockwise: strict selection (LED light->dark)

STEP5


Gray Line Counter (+/-) Red Line DC+12V


White Line O—Coin Signal

Black LINE O—GND (Ground)
Gray Line O—Counter (+/-)

999999 Counter


#### STEP6





FC-P0007 Coin Box

Coin Box Manual



size: W175mm x L145mm x H175mm

FC-P0030 Maintenance Door-Medium

## Maintenance Door-Medium Manual



size: W164mm x L20mm x H272mm

Page 8
Contents

Part list - F-16 FIGHTER PLANE FRP Model Assembly

## Item not illustrated

ltem No	Part No	Description	QTY
-	FC-088	F-16 FIGHTER PLANE FRP Model	
1	FC-P0019	Acrilan cover#1	1
2	FC-P0020	Light#1	1
3	FC-P0016	Steering wheel#2	1
4	FC-P0026	Electronic coin machine	1
5	FC-P0007	Coin box	1
6	FC-P0030	Maintenance door-medium	1
7	FC-P0021	Light#2	5
8	FC-P0022	Light#3	2
9	FC-P0032	Power-plug locates at rear of base	1
10	FC-P0024	Fixer	6
11	FC-P0025	Wheel	4
12	FC-S0015	Control door	1
13	FC-P0001	Double frame	1
14	FC-M0003	Music box	1
15	FC-P0003	Controller	1
16	FC-S0014	Base of cloud shape	1
17	FC-S0017	Ladder	1
18	FC-P0023	Handlebar#1	2
19	FC-S0016	FRP model of F-16 Fighter Plane	1
20	FC-P0027	Key#1	1
21	FC-P0028	Key#2	1
s1	FC-ST002	Sticker#1(U.S.A)	2
s2	FC-ST003	Sticker#2(FC-088)	2
s3	FC-ST004	Sticker#3(F-16)	2
s4	FC-ST005	Sticker#4(flag)	2
s5	FC-ST006	Sticker#5(flag)	2
s6	FC-ST001	Warning Sign Sticker	2